

Instructions for installation and use

ThermoFLUX DC INVERTER HEAT PUMP



ThermoFLUX

Contents

Part 1. Before use.....	2
1. Attentions.....	2
2. Installation.....	4
2.1. Heat pump installation location and attentions.....	4
2.2. Installation diagram and tips.....	5
2.3. Pre-start up.....	8
3. Part2.Use.....	9
3.1. Buttons function.....	10
3.2. APP function	21
3.3. Parameters query and setting.....	27
4. Part 3.Maintenance and repairing.....	28
4.1. Maintenance Typs.....	28
4.2. Error input and protection alarm.....	30
4.3. Other problem and repairing.....	36
Warranty	37

Part 1. Before Use

1. Attentions



Warning



Caution




Prohibition




This appliance is not intended for use by persons, including children, with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.




Be sure to read this manual before use.



Be sure to read this manual before use. The installation, dismantling and maintenance of the unit must be performed by qualified personnel. It is forbidden to do any changes to the structure of the unit. Otherwise injury of person or unit damage might happen.









The power supply to the unit must be grounded.



Make sure the power supply to the heat pump unit is off before any operations are done on the unit. When the power cord gets looser or is damaged, always get a qualified person to fix it.




Keep the unit away from the combustible or corrosive environment.



2. Installation


2.1. Heat pump installation location and attentions

- * Heat pump is not allowed to be installed in the place where combustible gas may leaks.
- * Heat pump is not allowed to be installed in the place where there is oil or corrosion gas released.
- * Heat pump should be installed in a open space, and good ventilating.
- * Heat pump each side to wall or barrel should be keep certain distance, air outlet to barrel distance should $\geq 2m$, air inlet distance to wall or barrel $\geq 0.5m$, bottom distance to ground $\geq 0.5m$, other side distance should be enough for installation or repairing.
- * Heat pump should be installed on concrete basic or steel bracket, and anti-shock pad should be put between heat pump and basic or bracket. Then use expansion bolt to fix heat pump on bracket.
- * Water drainage pipe and ditch should be set around heat pump and water pipes and water tank. When testing or repairing, maybe need drain plenty of water, and when heat pump is working, there are some condensed water flow down.



2.2. Installation diagram and tips (for reference only, installation shall be based on actual project demand)

Primary circulation system



Tips for installation related to the water pipe part:

- Install a valve at the highest point of each water circulations for releasing air from water system.
- A Y-shape filter is very important in front of circulating water pump of heat pump.
- If more pieces heat pump installed in one water pipe system, the connection of these heat pumps can't be in series, only can be in parallel or independent.

2.3. Pre-start up

① Checking before pre-start up

- Check if the water pipe are connected well and if there is any leakage. The water supply valve are open.
- Make sure the water flow is enough and meet the demand of the heat pump selected and water flow smoothly without air . In cold area, pls make sure that the water flow is without freezing
- Check if the power cable is connected well and properly grounded.
- Check if fan blade is blocked by the fixing plate of fan blade and fan blade protecting grill.
- Check if the tank has been filled with water or enough water volume that can meet the demand of heat pump running




If everything above is OK, the unit can start up. If any of them fails, please improve it.

② Pre-start up


- After check completely and confirm no problem for installation, the unit can be power to start up .
- After connect power supply, heat pump delay 3mins to start. Check carefully is there is some abnormal noise or vibration or if the working current is normal or if water temp increasing is normal.
- After the unit is working properly for 10 minutes without any problem, then the pre-start up is usefully completed. If not, pls refer to Service and Maintenance Chapter to solve the problem.


3. Part 2. Use

Main interface



The icon:


1, Heating mode 

2, Pump 

3, Compressor 

4, Fan 

5, Defrost 


6, Cooling mode 

7, Alarm 

8, Exit 






9, Menu & Confirm 

10, Select 

11, Factory parameters 






3.1. Button functions

3.1.1. Turn on/off


Press  to access menu, press  button to select Unit On/Off, then press  to confirm. Press  Button to turn on/off, and press  to confirm:



3.1.2. Mode switching (Heating, Cooling, Hot water, Hot water+cooling, Hot water+heat)

Press  to access menu, press  button to select User Mask, then press  to confirm. Press  button to switch mode, and press  to confirm, Egc. Mode switching&Temperature setting.

Attention: Only switch mode when the unit is turn off



The setting temperature interface is as follows:

Heating setp: heating setting temperature

Cooling setp: cooling setting temperature

Hotwater setp: hot water setting temperature

Setpoint	U01
Heating setp.:	45.0°C
Cooling setp.:	12.0°C
Hotwater setp.:	50.0°C

Set Temp.diff and Stop temp. diff. of hot water

Temp.diff: The difference between the unit restart temperature and the set temperature after standby.

Stop temp.diff: The difference between the unit's shutdown temperature and the set temperature after reaching the setting temperature.

Setpoint	U02
Hot water setp.	
Temp. diff.:	5.0°C
Stop temp. diff.:	0.0°C

Set Temp.diff and Stop temp. diff. of heating and cooling

Temp.diff: The difference between the unit restart temperature and the set temperature after standby.

Stop temp.diff: The difference between the unit's shutdown temperature and the set temperature after reaching the setting temperature.

Setpoint	U03
Cool and heat mode	
Temp. diff.:	5.0°C
Stop temp. diff.:	2.0°C

Set PID

Kp: The larger the value, the faster the heat pump adjustment speed (not recommended to adjust this parameter).

Integral and Differential: (not recommended to adjust this parameter).

Setpoint		U04
PID management		
Kp:		5.0°C
Integral:		200s
Differential:		0s

Pump work:

Normal - the water pump is always on during standby; Interval, the water pump is on every 3 minutes during standby;

Demand - the water pump stops during standby.

Pump auto:

ENABLE - the water pump is automatically turned on according to the temperature difference adjustment;

DISABLE - the water pump is automatically turned off according to the temperature difference adjustment.

Pump control		U05
Pump work:		Interval
Pump auto:		ENABLE

Fan mode:

Ecomode - economic mode, the heat pump can automatically output capacity as required according to the ambient temperature;

Nigt - night mode, the heat pump has low output capacity from 8 pm to 8 am, and high output at other times; Daytime, day mode, the compressor outputs according to the maximum capacity; Pressure, test mode, the heat pump outputs according to the test capacity.

Enable heater:

ALL-both floor heating and hot water mode enable electric heating; This mode electric heater must be installed on the main pipe.

Heating-only start electric heating in heating mode; This mode electric heater must be installed in the expansion water tank.

Hot water-only enable electric heating in hot water mode; This mode electric heater must be installed in the hot water tank.

Disable - disable electric heating.

Enable chassis/crack:

Enable - enable chassis electric heating/crankshaft electric heating;

Disable - disable chassis electric heating/crankshaft electric heating.

User configure	U06
Fan mode:	Daytime
Enable heater:	ALL
Enable chassis/crack heater:	Enable

Heater control:

Comp.delay: The delay time to start the electric heating after the compressor starts, the default is 50 minutes.

Ext.temp.setp: The maximum allowable ambient temperature for starting electric heating, the default is -15 degrees.

Heater control	U07
Comp.delay:	50min
Ext.temp. step.:	-15.0°C

Delta temp.set:

Variable frequency water pump speed adjustment target value of temperature difference between inlet and outlet water: the default is 5 degrees;

The output of the variable frequency water pump increases when the temperature difference between the inlet and outlet water is greater than 5 degrees, and the output of the variable frequency pump decreases when the temperature difference between the inlet and outlet water is less than 5 degrees.

Pump control	U08
Delta temp. set:	5.0°C

Auto start:

Disable - after the heat pump is powered off, the heat pump will not automatically start;

Enable - the heat pump will automatically start after the heat pump is powered off

User configure	U09
Auto start:	Enable

Enable Switch:

Disable - turn off the function of automatically switching the cooling/heating mode based on the ambient temperature;

Enable - turn on the automatic switching of the cooling/heating mode based on the ambient temperature.

AmbTemp Switch setp: Switch the ambient temperature setting point of the cooling/heating mode;

when the ambient temperature is lower than the set point-hysteresis, the unit will automatically switch to heating or hot water + heating;

when the ambient temperature is higher than the set point +In case of hysteresis, the unit will automatically switch to cooling or hot water+refrigeration;

when the ambient temperature is higher than the set point-hysteresis and lower than the set point + hysteresis maintains the current mode

Amb Temp.diff: The difference between the ambient temperature switching mode and the set temperature.

AmbTemp Switch U10	
Enable Switch	Disable
AmbTemp Switch	
Setp.:	20.0°C
Amb Tem.diff:	4.0°C






Economic model setting: On the following page, you can set different ambient temperature set points and water temperature settings in cooling, heating and hot water modes under economy mode; X is the set point of ring temperature and Y is the set point of water temperature.

Eco. mode-Cool U11	
Amb Temp.	Step.
X1: 20.0°C	Y1: 15.0°C
X2: 25.0°C	Y2: 15.0°C
X3: 30.0°C	Y3: 12.0°C
X4: 35.0°C	Y4: 12.0°C

Eco. mode-Heat U12	
Amb Temp.	Step.
X1: -10.0°C	Y1: 45.0°C
X2: 0.0°C	Y2: 40.0°C
X3: 10.0°C	Y3: 40.0°C
X4: 20.0°C	Y4: 35.0°C

Eco. mode-Hotwater U13	
Amb Temp.	Step.
X1: -10.0°C	Y1: 50.0°C
X2: 0.0°C	Y2: 50.0°C
X3: 20.0°C	Y3: 50.0°C
X4: 30.0°C	Y4: 45.0°C

3.1.3. TimeZone/CLOCK

Press  to access menu, press  button to select TimeZone/CLOCK, then press  to confirm, Press  Button to change the setting, and press  to confirm.



Timezone on off:


Enabl - Turn on the timer switch function, the unit can be set to switch on and off time for one week after it is switched on;

Disabl - Turn off the timer switch function.

Timezone setpoint:

Enabl - Turn on the timer temperature setting function, the unit can set different temperatures in four time periods of a day after it is turned on;

Disabl - Turn off the timer setting temperature function.



Timezone on off

Timing setting interface, under ON is the power-on time, and under OFF is the off-time.

Clock mng.		C103
Timeband1		
	ON	OFF
Mon.:	0:0	0:0
Tue.:	0:0	0:0
Wed.:	0:0	0:0
Thu.:	0:0	0:0

Clock mng.		C103-1
Timeband1		
	ON	OFF
Fri.:	0:0	0:0
Sat.:	0:0	0:0
Sun.:	0:0	0:0

Clock mng.		C104
Timeband2		
	ON	OFF
Mon.:	0:0	0:0
Tue.:	0:0	0:0
Wed.:	0:0	0:0
Thu.:	0:0	0:0

Clock mng.		C104-1
Timeband2		
	ON	OFF
Fri.:	0:0	0:0
Sat.:	0:0	0:0
Sun.:	0:0	0:0

Timezone setpoint Timing setting temperature interface;

Timezone1 is the start time of the first time period, **Timezong2** is the cut-off time of the first time period and the start time of the second time period, and so on.

Cooling temp、**Heating temp**、**Tank temp** Set the temperature for cooling, heating, and hot water for the corresponding time period



Clock mng.		C105
Timezone1:	0:0	
Cooling temp.:	0.0°C	
Heating temp.:	0.0°C	
Tank temp.:	0.0°C	

Clock mng.		C106
Timezone2:	0:0	
Cooling temp.:	0.0°C	
Heating temp.:	0.0°C	
Tank temp.:	0.0°C	

Clock mng.		C107
Timezone3:	0:0	
Cooling temp.:	0.0°C	
Heating temp.:	0.0°C	
Tank temp.:	0.0°C	

Clock mng.		C108
Timezone4:	0:0	
Cooling temp.:	0.0°C	
Heating temp.:	0.0°C	
Tank temp.:	0.0°C	

3.1.4. Input/Output




Press  to access menu, press \uparrow/\downarrow button to select I/O mask, then press  to confirm, Press \uparrow/\downarrow Button to see the I/O, E.gc Water temperature/ Pressure/Frequency and so on.




M02	
Press ENTER to switch I/O mask	

Input/output	Sn01
B1:Inlet temp.	40°C
B2:Outlet temp.	45°C
B3:Ext temp.	20°C

Input/output	Sn02
B4:Disch. gas temp.	80°C
B5:Suct. gas temp.	13°C
B6:Disch. press.	28.4bar

Input/output	Sn03
B7:Suct. press.	9.8bar
B8:Hotwater temp.	55°C
B9:Coil temp.	10°C

Input/output	Sn05
Digit input status	
ID1:Flow switch	
ID2:linkage switch	
ID3:A/C linkage switch	

Input/output	Sn06
Digit input status	
ID4:Cooling Linkage	
ID5:Phase. switch	
ID6:Heating linkage	

Input/output	Sn07
Digit . output status	
D01:Fan high speed	
D02:Fan low speed	
D03:4 way valve	

Input/output	Sn08
Digit . output status	
D04:Pump	
D05:Chassis heater	
D06:Crank heater	

Input/output	Sn09
Digit . output status	
D07:Three valve	
D08:Terminal Pump	
D09: Heater	


Input/output	Sn10
Analog. output status	
Y1:fan output	0.0%
Y3:Pump output	0%

Firmware version information query: Switch to the last page to query the firmware and software information of the controller

Information	
Code:	1 2 5
Ver.:	6111 00
Date:	CGK-060V2
OS:	2021.06.19
	4.6.001

3.2. APP function

3.2.1. Device Homepage



Explanation


- 1) Click a device in the device list to enter this page.
- 2) The background color of the bubble indicates the current operating state of the device:
 - a. Gray indicates that the device is in the shutdown state, at this time, you can change the working mode, set the mode temperature, set the timing, or you can press the key to switch on and off.
 - b. Multicolor indicates that the device is turned on, each working mode corresponds to a different color, orange indicates heating mode, red

indicates hot water mode, and blue indicates cooling mode.


- c. When the device is in the power-on state, you can set the mode temperature, set the timer, press the key to switch on and off, but you can not set the working mode (that is, the working mode can only be set when the device is off)
- 3) The bubble shows the current temperature of the device.
- 4) Below the bubble is the set temperature of the device in the current operating mode.
- 5) Set the temperature is about **+**, **-** button, Each click adds or subtracts the current setting value to the device.
- 6) Below the setting temperature is the Fault And Alert. When the device starts to alarm, the specific Alert reason will be displayed next to the yellow warning icon. In case of device Fault And Alert, the Fault And Alert content will be displayed on the right side of this area. Click this area to jump to the detailed Error Information.

Error Info	
AlrmResByBms	NONE
Too many mem writings	OK
Retain mem write error	OK
Inlet probe error	OK
Outlet probe error	OK
Ambient probe error	OK
Condenser coil temp	OK
Water flow switch	OK
Phase sequ.prot.alarm	OK
Unit work hour warning	OK
Pump work hour warning	OK
Comp.work hour warning	OK
Cond.fan work hourWarn	OK
Low superheat - Vlv.A	OK

- 7) Immediately below the fault alarm area, display the current working mode, heat pump, fan and compressor in sequence (corresponding blue icon when it is on, but not displayed when it is off).
- 8) The slide bar below is used to set the temperature in the current mode. Slide the slider left and right to set the allowable temperature in the current working mode.
- 9) The bottom three buttons are in order from left to right: working mode, device switching machine and device timing. When the current background is color, the working mode button cannot be clicked.
 - a. Click Work Mode to see the mode selection menu, and you can set the working mode of the device (black is the current setting mode of the device). The diagram as below:



- b. Click "on/off" and set "on/off" command to the device.
- c. Click the device Timer to see the Timer Settings menu. Click the Clock Schedule to set the device Timer function. The diagram below:



Detailed information of the units

Note :

- 1) Click this Main Interface menu on the upper right corner to enter this setting page.
- 2) Users with manufacturer rights can check all the functions , including:
User mask, defrost , other parm, factory settings, manual control , query parm, time edit, error info.

< <input type="text" value="Search Opration Name"/>			
User Mask	Query Parm	TimeEdit	Error Info
CoolHeat_Mode	Heat		
HeatSetP	42.00		
CoolSetP	27.00		
W_TankSetP	52.00		
Hotwater_start_diff	5.00		
Hotwater_stop_diff	27.00		
Temp_Diff	5.00		
Stop_Temp_Diff	2.00		
Kp	5.00		
Ti	200		
Td	0		
PmpMode	Setting		
FanMode_Sel	Day		
En_AuxHeat	N		

3) User with user rights , only can check part of the functions: User mask, query parm, TimeEdit , alarms.

3.3. Parameters query and setting

Parameter Name		Initial Value
Unit mode		Heating
Heating setp.		45°C
Cooling setp.		12°C
Hotwater setp.		50°C
Temp. diff.		5°C
Stop temp. diff.		0°C
Cool and heat mode Temp. diff.		5°C
Stop temp. diff.		2°C
Kp		5°C
Integral		200s
Differential		0s
Pump work		Interval
Pump Auto		Enable
Fan model		Daytime
Enable heater		Enable
Enable chassic/crack heater		Enable
Heater control-Comp. delay		50min
Heater control-Ext.temp.setp.		-15°C
Pump control	Delta temp. set.	5°C
Auto start		Enable

4. Part 3. Maintenance and repairing

4.1. Maintenance Tips

The heat pump unit is a highly automated equipment. The unit status check is carried out regularly during use. If the unit can be maintained and maintained for a long time and effectively, the unit's operational reliability and service life will be unexpectedly improved.

- 1、 Users should pay attention to the use and maintenance of this unit: all safety protection devices in the unit are set before leaving the factory, do not adjust by yourself;
- 2、 Always check whether the power supply and electrical system wiring of the unit is firm, whether the electrical components are malfunctioning, and if necessary, repair and replace them in time;
- 3、 Always check the water system's hydration, the water tank safety valve, the liquid level controller and the exhaust device to work properly, so as to avoid the air circulation into the system and reduce the water circulation, thus affecting the unit's heating capacity and unit operation reliability;
- 4、 The unit should be kept clean and dry and well ventilated. Regularly clean (1-2 months) air-side heat exchangers to maintain good heat transfer;
- 5、 Always check the operation of each component of the unit, check the oil pipe at the pipe joint and the gas valve, and ensure that the refrigerant of the unit is not leaking;
- 6、 Do not stack any debris around the unit to avoid blocking the air inlet and outlet. The unit should be clean and dry and well ventilated.
- 7、 If the downtime is long, the water in the unit piping should be drained, and the power supply should be cut off and the protective cover should be placed. When running again, check the system thoroughly before starting up;

- 8、 If the unit fails and the user cannot solve the problem, please inform the company's special maintenance department in order to send someone to repair it in time;
- 9、 The main unit condenser cleaning, the company recommends using a 50 ° C concentration of 15% hot oxalic acid to clean the condenser, start the host with a circulating water pump for 20 minutes, and finally rinse with tap water 3 times. (It is recommended to reserve a three-way interface when installing the pipe and seal one interface with a wire plug) in case of cleaning. Do not wash the condenser with a corrosive cleaning solution. The water tank needs to be removed after a period of use (usually two months, depending on local water quality).

4.2. Error input and protection alarm

AL001	AL001 Too many mem writings
AL002	AL002 Retain mem write error
AL003	AL003 Inlet probe error
AL004	AL004 Outlet probe error
AL005	AL005 Ambient probe error
AL006	AL006 Condenser coil temp
AL007	AL007 Water flow switch
AL008	AL008 Phase sequ.prot.alarm
AL009	AL009 Unit work hour warning
AL010	AL010 Pump work hour warning
AL011	AL011 Comp.work hour warning
AL012	AL012 Cond.fan work hourWarn
AL013	AL013 Low superheat - Vlv.A
AL014	AL014 Low superheat - Vlv.B
AL015	AL015 LOP - Vlv.A
AL016	AL016 LOP - Vlv.B
AL017	AL017 MOP - Vlv.A
AL018	AL018 MOP - Vlv.B
AL019	AL019 Motor error - Vlv.A
AL020	AL020 Motor error - Vlv.B
AL021	AL021 Low suct.temp. - Vlv.A
AL022	AL022 Low suct.temp. - Vlv.B
AL023	AL023 High condens.temp.EVD
AL024	AL024 Probe S1 error EVD
AL025	AL025 Probe S2 error EVD
AL026	AL026 Probe S3 error EVD
AL027	AL027 Probe S4 error EVD

AL028	AL028 Battery discharge EVD
AL029	AL029 EEPROM alarm EVD
AL030	AL030 Incomplete closing EVD
AL031	AL031 Emergency closing EVD
AL032	AL032 FW not compatible EVD
AL033	AL033 Config. error EVD
AL034	AL034 EVD Driver offline
AL035	AL035 BLDC-alarm:High startup DeltaP
AL036	AL036 BLDC-alarm:Compressor shut off
AL037	AL037 BLDC-alarm:Out of Envelope
AL038	AL038 BLDC-alarm:Starting fail wait
AL039	AL039 BLDC-alarm:Starting fail exceeded
AL040	AL040 BLDC-alarm:Low delta pressure
AL041	AL041 BLDC-alarm:High discharge gas temp
AL042	AL042 Envelope-alarm:High compressor ratio
AL043	AL043 Envelope-alarm:High discharge press.
AL044	AL044 Envelope-alarm:High current
AL045	AL045 Envelope-alarm:High suction pressure
AL046	AL046 Envelope-alarm:Low compressor ratio
AL047	AL047 Envelope-alarm:Low pressure diff.
AL048	AL048 Envelope-alarm:Low discharge pressure
AL049	AL049 Envelope-alarm:Low suction pressure
AL050	AL050 Envelope-alarm:High discharge temp.
AL051	AL051 Power+ alarm:01-Overcurrent
AL052	AL052 Power+ alarm:02-Motor overload
AL053	AL053 Power+ alarm:03-DCbus overvoltage
AL054	AL054 Power+ alarm:04-DCbus undervoltage
AL055	AL055 Power+ alarm:05-Drive overtemp.
AL056	AL056 Power+ alarm:06-Drive undertemp.
AL057	AL057 Power+ alarm:07-Overcurrent HW
AL058	AL058 Power+ alarm:08-Motor overtemp.

AL059	AL059 Power+ alarm:09-IGBT module error
AL060	AL060 Power+ alarm:10-CPU error
AL061	AL061 Power+ alarm:11-Parameter default
AL062	AL062 Power+ alarm:12-DCbus ripple
AL063	AL063 Power+ alarm:13-Data comm. Fault
AL064	AL064 Power+ alarm:14-Thermistor fault
AL065	AL065 Power+ alarm:15-Autotuning fault
AL066	AL066 Power+ alarm:16-Drive disabled
AL067	AL067 Power+ alarm:17-Motor phase fault
AL068	AL068 Power+ alarm:18-Internal fan fault
AL069	AL069 Power+ alarm:19-Speed fault
AL070	AL070 Power+ alarm:20-PFC module error
AL071	AL071 Power+ alarm:21-PFC overvoltage
AL072	AL072 Power+ alarm:22-PFC undervoltage
AL073	AL073 Power+ alarm:23-STO DetectionError
AL074	AL074 Power+ alarm:24-STO DetectionError
AL075	AL075 Power+ alarm:25-Ground fault
AL076	AL076 Power+ alarm:26-Internal error 1
AL077	AL077 Power+ alarm:27-Internal error 2
AL078	AL078 Power+ alarm:28-Drive overload
AL079	AL079 Power+ alarm:29-uC safety fault
AL080	AL080 Power+ alarm:98-Unexpected restart
AL081	AL081 Power+ alarm:99-Unexpected stop
AL082	AL082 Power+ safety alarm:01-Current meas.fault
AL083	AL083 Power+ safety alarm:02-Current unbalanced
AL084	AL084 Power+ safety alarm:03-Over current
AL085	AL085 Power+ safety alarm:04-STO alarm
AL086	AL086 Power+ safety alarm:05-STO hardware alarm
AL087	AL087 Power+ safety alarm:06-PowerSupply missing
AL088	AL088 Power+ safety alarm:07-HW fault cmd.buffer
AL089	AL089 Power+ safety alarm:08-HW fault heater c.

AL090	AL090 Power+ safety alarm:09-Data comm. Fault
AL091	AL091 Power+ safety alarm:10-Compr. stall detect
AL092	AL092 Power+ safety alarm:11-DCbus over current
AL093	AL093 Power+ safety alarm:12-HWF DCbus current
AL094	AL094 Power+ safety alarm:13-DCbus voltage
AL095	AL095 Power+ safety alarm:14-HWF DCbus voltage
AL096	AL096 Power+ safety alarm:15-Input voltage
AL097	AL097 Power+ safety alarm:16-HWF input voltage
AL098	AL098 Power+ safety alarm:17-DCbus power alarm
AL099	AL099 Power+ safety alarm:18-HWF power mismatch
AL100	AL100 Power+ safety alarm:19-NTC over temp.
AL101	AL100 Power+ safety alarm:20-NTC under temp.
AL102	AL102 Power+ safety alarm:21-NTC fault
AL103	AL103 Power+ safety alarm:22-HWF sync fault
AL104	AL104 Power+ safety alarm:23-Invalid parameter
AL105	AL105 Power+ safety alarm:24-FW fault
AL106	AL106 Power+ safety alarm:25-HW fault
AL107	AL107 Power+ safety alarm:26-reseved
AL108	AL108 Power+ safety alarm:27-reseved
AL109	AL109 Power+ safety alarm:28-reseved
AL110	AL110 Power+ safety alarm:29-reseved
AL111	AL111 Power+ safety alarm:30-reseved
AL112	AL112 Power+ safety alarm:31-reseved
AL113	AL113 Power+ safety alarm:32-reseved
AL114	AL114 Power+ alarm:Power+ offline
AL115	AL115 EEV alarm:Low superheat
AL116	AL116 EEV alarm:LOP
AL117	AL117 EEV alarm:MOP
AL118	AL118 EEV alarm:High condens.temp.
AL119	AL119 EEV alarm:Low suction temp.
AL120	AL120 EEV alarm:Motor error

AL121	AL121 EEV alarm:Self Tuning
AL122	AL122 EEV alarm:Emergency closing
AL123	AL123 EEV alarm:Temperature delta
AL124	AL124 EEV alarm:Pressure delta
AL125	AL125 EEV alarm:Param.range error
AL126	AL126 EEV alarm:ServicePosit% err
AL127	AL127 EEV alarm:ValveID pin error
AL128	AL128 Low press alarm
AL129	AL129 High press alarm
AL130	AL130 Disc.temp.probe error
AL131	AL131 Suct.temp.probe error
AL132	AL132 Disc.press.probe error
AL133	AL133 Suct.press.probe error
AL134	AL134 Tank temp.probe error
AL135	AL135 EVI SuctT.probe error
AL136	AL136 EVI SuctP.probe error
AL137	AL137 Flow switch alarm
AL138	AL138 High temp. alarm
AL139	AL139 Low temp. alarm
AL140	AL140 Temp.delta alarm
AL141	AL141 EVI alarm:Param.range error
AL142	AL142 EVI alarm:Low superheat
AL143	AL143 EVI alarm:LOP
AL144	AL144 EVI alarm:MOP
AL145	AL145 EVI alarm:High condens.temp.
AL146	AL146 EVI alarm:Low suction temp.
AL147	AL147 EVI alarm:Motor error
AL148	AL148 EVI alarm:Self Tuning
AL149	AL149 EVI alarm:Emergency closing
AL150	AL150 EVI alarm:ServicePosit% err
AL151	AL151 EVI alarm:ValveID pin error

AL152	AL152 Supply power error
AL153	AL153 Fan1 fault
AL154	AL154 Fan2 fault
AL155	AL155 Fans Offline
AL165	AL165 Slave1 Offline
AL166	AL166 Master Offline
AL167	AL167 Slave2 Offline
AL168	AL168 Slave3 Offline
AL169	AL169 Slave4 Offline
AL170	AL170 Slave5 Offline
AL171	AL171 Slave6 Offline
AL172	AL172 Slave7 Offline
AL173	AL173 Slave8 Offline
AL174	AL174 Slave9 Offline

4.3. Other problem and repairing

No	Error	Possible reason	Method
1	Heat pump doesn't run	<ol style="list-style-type: none"> 1. Power supply cable is loose 2. The fuse of power supply is fused. 	<ol style="list-style-type: none"> 1. Cut off the power supply to check and repair. 2. Change the fuse.
2	Heating capacity is too small	<ol style="list-style-type: none"> 1. Refrigerant is not enough 2. Water system insulating is not good 3. Air heat exchanger is dirty 4. Water heat exchanger scaled 	<ol style="list-style-type: none"> 1. Check leakage and repair and refill gas 2. Improve the insulation 3. Clean air heat exchanger 4. Clean water heat exchanger
3	Compressor doesn't run	<ol style="list-style-type: none"> 1. Power supply has error 2. Cable connecting is loose 3. Compressor is overheat 	<ol style="list-style-type: none"> 1. Check reason and solve 2. Check loose and repair 3. Check reason and repair
4	Compressor noise is loud	<ol style="list-style-type: none"> 1. Expansion valve damaged lead to liquid entering compressor 2. The internal parts of compressor damaged 3. Compressor lack of oil 	<ol style="list-style-type: none"> 1. Change expansion valve 2. Change compressor 3. Compensate oil for compressor
5	Fan motor doesn't run	<ol style="list-style-type: none"> 1. Fan blade fixing screw is loose 2. Fan motor damaged 3. Fan motor capacitance damaged 	<ol style="list-style-type: none"> 1. Tight the screw 2. Change fan motor 3. Change the capacitance
6	Compressor run, but not heat	<ol style="list-style-type: none"> 1. There is not refrigerant at all 2. Compressor damaged 	<ol style="list-style-type: none"> 1. Check leakage and repair 2. Change compressor

Warranty card

Product model:

Bar code:

Buyer		Address	
Invoice No.		Date	
Repair date	Repair record		Repairer

Items of warranty:

1. Warranty terms: _____; Within warranty, any problem because of quality, please contact us for support.
2. When repair needed, please show the warranty card and invoice of order or other proof.
3. We don't afford the problem that is caused by re-fitment or adding other function by user.
4. Warranty card and invoice or other purchasing proof will be invalid if alerted.
5. Please keep the warranty card and invoice or other purchasing proofs well, we will need these for service purpose.
6. We will not provide free warranty for below conditions:
 - (1) without proof;
 - (2) errors caused by re-fitment or not correct operating;
 - (3) damage caused by not professional people operating;
 - (4) faulty by moving or falling;
 - (5) faulty caused by natural disaster;
 - (6) After the power failure, the water in the pipeline of the unit was not discharged, which caused the unit to freeze.

CERTIFICATE

Product Model: _____

Bar code: _____
